

EVERCHILL RESET

1. Hold set button for 10 seconds and refer will turn off.
2. Hold set button for 10 seconds and refer will turn on.
3. Set freezer dial to 3 and refer to 5.
4. The freezer supports the refer temperature.
5. To do a hard reset, turn the disconnect off to the coach for 10 minutes.
6. Now do step 1, 2 and 3.